

**HÜRNER**



**HÜRNER**  
SCHWEISSTECHNIK

Bedienungsanleitung • User's Manual • Manuel utilisateur

# WeldControl 2.0 160



**HÜRNER SCHWEISSTECHNIK GmbH**  
Nieder-Ohmener Str. 26  
35325 Mücke (Atzenhain)

+49 (0)6401 91 27 0  
+49 (0)6401 91 27 39  
info@huerner.de  
<http://www.huerner.de>

**HÜRNER**  
SCHWEISSTECHNIK

Version September 2017

# Contents

1	Introduction .....	5
2	Safety Messages .....	5
2.1	The User's Manual.....	5
2.2	Explaining Icons .....	5
2.3	Operating the Product Safely.....	5
2.4	Owner and Operator Obligations.....	6
2.5	Intended Use .....	7
2.6	Warranty.....	7
2.7	Transport and Storage .....	7
2.8	Identifying the Product .....	7
3	Understanding the Machine .....	7
3.1	Included Components.....	8
3.2	Control Panel.....	8
3.3	Connectors.....	8
3.4	Technical Specifications .....	9
3.5	Overview of the Welding Process .....	10
4	Operation .....	11
4.1	Configuring the Machine, Entering Welding Parameters.....	11
4.1.1	Setting the Default Configuration of the Machine .....	12
4.1.2	Understanding the "Settings" Sub-menu .....	12
4.1.3	Selecting the Display Language .....	13
4.1.4	Setting the Clock.....	13
4.1.5	Setting the Buzzer Volume.....	13
4.1.6	Understanding the "Recording" Sub-menu.....	14
4.2	Entering Preformatted and User-defined Traceability Data .....	14
4.2.1	Entering the Welder ID Code .....	14
4.2.2	Entering or Changing the Commission Number .....	15
4.2.3	Entering or Changing the Joint Number.....	15
4.2.4	Entering oder Changing Further Data on Component Traceability .....	16
4.3	Butt Welding in the WeldControl Mode .....	16
4.3.1	Facing the Pipe Butts .....	17
4.3.2	Checking Pipe Alignment and Determining Drag Pressure .....	17
4.3.3	Possibility to Change Welding Parameters.....	18
4.3.4	Setting the Joining Pressure and Starting the Bead Build-up Stage .....	18
4.3.5	Heating Stage.....	18
4.3.6	Change-over Stage.....	19
4.3.7	Joining and Cooling Stage .....	19
4.3.8	End of Welding .....	20
4.4	Fully Manual Butt-welding Process.....	20
4.4.1	Bead Build-up Stage .....	21
4.4.2	Heating Stage.....	21
4.4.3	Change-over Stage.....	21
4.4.4	Joining and Cooling Stage .....	22
4.4.5	End of Welding .....	22
4.5	Aborted Welding Process .....	22
4.6	Using ViewWeld to View Welding Reports and Print Tags .....	23
5	Downloading the Reports .....	23
5.1	Selecting the File Format.....	24
5.2	Downloading All Reports .....	24
5.3	Downloading by Commission Number, Date or Report Range.....	24
5.4	Understanding the Report Download Process.....	24
5.5	Deleting Data from Memory.....	25
5.6	Keeping Data in Memory .....	25

6	Service and Repair.....	25
7	Service and Repair Contact.....	25
8	Accessories/Parts for the Product.....	25
	Appendix.....	27



**The success of the jointing operation depends on the proper pressures, times, and temperatures of the welding as given in the welding value tables in the appendix. The correct pressure value depends on the section of the cylinder of the welding machine. Prior to using the tables in the appendix, verify carefully that the section quoted in the technical specifications of this manual is the same as the section given on the name plate affixed to your machine.**

## 1 Introduction

Dear Customer:

Thank you very much for purchasing our product. We are confident that it will bring you success and meet your expectations.

The development, manufacture, and check of the butt-welding system **HÜRNER WeldControl 2.0 160** has been performed with a view to superior operation safety and user-friendliness. The system was manufactured and checked according to state-of-the-art technology and widely recognized safety provisions.

To ensure maximum operation safety, please conform to the appropriate messages in this booklet and the rules for the prevention of accidents.

Thank you.

## 2 Safety Messages

This User's Manual contains important instructions for the intended and safe operation of the product. Every person who operates the product has to conform to the instructions of this manual.

### 2.1 The User's Manual

The User's Manual is presented according to sections which explain the different functions of the product.

All rights, in particular the right to copy or reproduce (in print or electronic form) and distribute as well as to translate, are reserved and subject to prior written consent.

### 2.2 Explaining Icons

The following expressions and icons are used in this User's Manual to refer to safety-related issues:



Caution

This icon indicates that non-compliance may result in a hazardous situation that possibly causes bodily injury or material damage.



Important

This icon indicates important messages related to the correct use of the product. Non-compliance may cause problems of operation and damage to the product.



Info

This icon indicates tips and useful information for using the product more efficiently and more economically.

### 2.3 Operating the Product Safely

For your own safety, comply with the following instructions

- Protect the power supply cord and the hydraulic pressure hoses from cutting edges. Have an authorized service shop replace damaged cables or hoses immediately.
- The product may be operated and serviced exclusively by authorized staff who were briefed on it.
- The product may be operated only when observed.
- Before operating the product, always check for damaged parts

and have them repaired or replaced by an authorized service shop as needed.

- The cover caps of the hydraulic hoses and connectors and the interface ports have to be closed during transport in order to prevent contaminants and humidity from entering the hydraulic and control unit.
- Mains suppliers' wiring regulations, VDE provisions, DIN/CE regulations, and applicable national legislation have to be respected.
- Without prior authorization by the manufacturer, modifications to the product are unacceptable.



Caution

#### Parts Under Power

After opening the machine or removing the cover, parts of it are accessible that may be under power. The machine may be opened exclusively by an authorized service shop.



Caution

#### Pipe Facing Tool

Start the pipe facing tool only after it was inserted into the machine and carry it only by the handle, never by the disk enclosure.

It is unacceptable to remove shavings from the machine while the facing process is in progress. Make sure nobody is present in this danger zone.



Caution

#### Heating Element

When working with the machine, be extremely cautious while the heating element is used. Since the heating element presents a temperature of more than 200°C during the welding process, it is absolutely indispensable that operators wear suitable protective gloves. Bear in mind that the heating element will remain hot for a while after it was turned off.



Caution

#### Danger of Bruises and Injury

Do not remain in the danger zone while the machine carriage moves apart or closes in, and be sure not to have your arms or legs between the moving and the fixed carriage of the machine.



Caution

#### Acceptable Work Conditions

The work zone has to be clean and has to have proper lighting. It is dangerous to operate while it is raining, in a humid environment, or close to flammable liquids. In regard of this, acceptable work conditions have to be ensured (tent, heating, etc.).



Info

#### User's Manual

The User's Manual has to be available at any time on the site where the machine is used. If the User's Manual becomes incomplete or unreadable, replace it without delay. Feel free to contact us for assistance.

## 2.4 Owner and Operator Obligations

- The product may be operated exclusively by persons who are familiar with the applicable rules, the guidelines for the prevention of accidents, and the User's Manual. The owner/manager shall provide the worker operating the system with the User's Manual and shall make sure that the operator reads and understands it.
- The system may be operated only when observed. Welders must have been briefed properly on the operation of the system or

must have participated in a dedicated training. The operating/owning organization engages to check at reasonable intervals if the system is operated by the welders as intended and under proper guidelines of occupational safety.

- The system must be operated only when in proper state of repair and for one of the intended uses. Before welding, the welder is required to make sure that the state of the system is in order.



Important

During transport, the facing tool and the heating element have to be placed into the provided carrying rack at all times.



Important

The dust cap for the data transfer interface port has to cover the port during operation, in order to keep humidity and contaminations away.

## 2.5 Intended Use

The welding system is intended exclusively for joining plastic pipes and fittings according to the butt-welding process with heating element. See Section 3 for an overview of the welding process enabled by this system.

The notion of intended use also includes:

- Compliance with the instructions in the User's Manual
- Observation of all service and maintenance intervals



Important

All uses other than those mentioned above are not allowed and will cancel any and all liability or warranty by the manufacturer. Unintended use may cause considerable hazards and material damage.

## 2.6 Warranty

Warranty claims may be raised only if the conditions for warranty given in the General Terms and Conditions of Sale and Delivery obtain.

## 2.7 Transport and Storage

The box in which the product ships should also be used for storage as a protection against humidity. During transport or storage in the box, the hydraulic tubing should **not be detached or squeezed**. The pipe facing tool and heating element have to be transported in the provided carrying rack.

## 2.8 Identifying the Product


Every product is identified by a name plate. It shows the model ("Typ"), the serial number ("Maschinennr."), and the manufacturer. The first two digits of the serial number represent the year of manufacture.

## 3 Understanding the Machine

This butt-welding machine for plastics can be used both as an on-site and as a workshop installation, for jointing operations pipe-to-pipe, but also for processing tees and elbows (see also the first paragraphs of Sect. 4.3 and 4.4 for more detailed information on this). The machine enables welding according to two modes, the Manual Mode and the Data Logging/Report Generation mode, or Weld Control Mode for short.

Stumpfschweißsystem	
Typ	WeldControl 2.0 160
Maschinennr.	14557001
Hürner Schweißtechnik	
Nieder-Ohmener Str. 26	
D - 35325 Mücke	
Tel. +49 6401 9127 0	
CE	





### 3.4 Technical Specifications

<b>HÜRNER WeldControl 2.0 160</b>	
<b>Power Specifications</b>	
Voltage	230 V
Frequency	50 / 60 Hz
Total Rated Power	2.45 kW
Heating Element	0.80 kW
Facing Tool	1.05 kW
Hydraulic & Control Unit	0.60 kW
<b>Hydraulic Specifications</b>	
Operating Pressure max.	160 bar
Cylinder	1.95 cm <sup>2</sup>
Hydraulic Oil	HF-E 15
Operating Range	40 through 160 mm
Ambient Temperature Range	-20°C à +60°C (+32°F thru +140°F)
Ingress Protection	IP54
Memory for Welding Reports	10,000 reports
Data Interface Port	USB v 2.0 (480 mbit/s) (see also data at the beginning of Sect. 5)
<b>Dimensions</b>	
Basic Machine Chassis	600 x 400 x 410 mm
Facing Tool	430 x 330 x 80 mm
Heating Element	450 x 350 x 50 mm
Hydraulic & Control Unit	480 x 310 x 300 mm
Carrying and Storage Rack	300 x 370 x 400 mm
<b>Weights</b>	
Basic Machine Chassis	27 kg
Facing Tool	8 kg
Heating Element	4 kg
Hydraulic & Control Unit	28 kg
Carrying and Storage Rack	4 kg
Transport Box	27 kg
All Reducer Inserts	21 kg



### 3.5 Overview of the Welding Process

The welding control program supports the extended data encoding specifications under the ISO 12176 standard, e.g., pipe and fitting traceability codes. To use this capability, the desired data have to be enabled in the configuration menu, at "Recording" (see Sect. 4.1).

All data that are relevant for the joint or for component traceability are saved to the internal memory and can be sent to a USB stick.

The welding parameters can also be entered manually. The welding system is microprocessor-controlled and:-

- controls and monitors the welding process in a fully automated way, when the welder starts it after component preparation,
- determines welding duration depending on ambient temperature,
- shows all information on the display in plain text.


In the **manual mode**, the machine performs a classic, manual butt-welding operation. It monitors the temperature of the heating element, taking the desired nominal temperature that can be set using the ↑ and ↓ cursor keys, into account, and readjusts it as needed.


In the **WeldControl mode**, the machine guides the welder through the welding process, monitors all relevant parameters, and allows entering traceability data for the welded components on intuitive menu screens. Parameters of the welding operation, component traceability data, and possible errors are recorded and saved to memory and can be transferred via one of two USB interface ports to a USB stick, a USB-compatible printer, or a PC with the management and database application DataWork.


The welder performs the butt-welding process in the following manner:


- Pipes are clamped into the frame.  
If pipes with an outside diameter smaller than the maximum dimension of the machine are welded, select the reducer set needed. The 8 individual inserts of the set that matches the outside diameter of the pipe to be welded have to be attached to the clamps of the machine chassis using the provided bolts.
- In the **manual mode**, applicable welding times and pressures are looked up in the overview tables in the appendix.
- In the **WeldControl mode**, the mandatory and the optional component traceability data are entered in the menus on the screen.
- Pipe butts are worked using the pipe facing tool.
- Pipe alignment is checked.
- The drag pressure, i.e. the minimum pressure to set the carriage in motion and "drag" it along, is recorded at the machine.
- The pressures relevant to the welding operation are set.
- The heating element is inserted after cleaning it and checking its temperature.
- The welding process proper is performed (see section 4), and the operator waits for the jointed pipes to cool down.
- After the cooling time is over, pressure can be shut off from the pipes (in the manual mode by the welder, in the WeldControl mode automatically by the machine) and the joint can be taken out of the chassis.

## 4 Operation


 To operate the welding system, be sure that it is set on a proper, level surface and that power supply protection is 16 A Important (slow blow).

 Before the control unit is turned on, check the oil level of the hydraulic and control unit and top up with HF-E 15 hydraulic oil as needed. Important

 The surfaces of the heating element have to be free of grease and clean, or they have to be cleaned. Important

 Make sure all connectors are tight in their sockets and note that operation on a worksite is only acceptable if the power Important supply has earth-leakage circuit breakers.

After connecting the power supply cord to the mains power supply or a generator, turn the machine on at the On/Off switch.

 It has to be ensured that the voltage of the power source the machine is connected to corresponds to the rated voltage of the machine. Also the following has to be respected when using extension cables: Caution

For 230 V power: wire section 1.5 mm<sup>2</sup> = max. 20 m long  
 wire section 2.5 mm<sup>2</sup> = max. 75 m long  
 wire section 4.0 mm<sup>2</sup> = max. 100 m long


### 4.1 Configuring the Machine, Entering Welding Parameters

After the machine was switched on, Display 1 shows on the screen.

The machine will then automatically start the auto-test process to check the sensors and the system clock and to determine the number of free welding reports. This test can be bypassed by holding down the STOP/RESET key when Display 1 is showing.

```
*****
*           HUERNER           *
*   WeldControl 2.0   *
*****
```

Display 1

 If during the auto-test an error is detected, a "System Error" message shows on the display. When this happens, the welding unit has to be disconnected immediately from the power supply and heating element/facing tool, and it has to be returned to the manufacturer for repair. Caution

```
Welding Standard
DVS
```

Display 2

Subsequent to a successful auto-test or after the test was bypassed, the machine first shows overview screens on the selected kind of machine and welding standard, then Display 3.

Display 3 shows the the data of the next welding, including time of day, date, report number, and joint number, along with, in the second-to-last line, the actual input voltage and—if the cable of the heating element for butt welding is connected—the actual and nominal heating element temperature before and after the slash.

```
Next welding
15:44:52   29.05.12
112V      135C/220C
Rep. No. 00072/00002
```

Display 3

From Display 3, it is possible to access the Configuration Menu in which the default behavior of the welding machine can be configured. To access it, press the MENU key and then, on the following enter code screen, type the access code using the cursor keys or hold the transponder card in front of the RFID reader.

CODE : 415311

Pressing the ↑ and ↓ cursor keys in the menu that appears (Display 4),

you can select a menu option, then access the selected sub-menu by pressing the MENU key again.

In the Machine Data sub-menu, the type of machine (its designation and its cylinder section) to which the hydraulic, control, and data logging/report generation unit is connected, has to be defined (see the arrow symbol in Display 5). This definition is preset ex works and needs changing only when, exceptionally, the control unit is connected to a different machine. To change it, select the proper machine type by pressing the  $\uparrow$  or  $\downarrow$  cursor keys and confirm by pressing the START/SET key.



Important

If the wrong machine is selected in this menu, all pressure computations that the machine makes when welding in the WeldControl mode, will be wrong! Changing to another machine requires consultation with the manufacturer or an authorized service shop, as a sensor calibration is then also recommended. This step requires proper authorization

```
Settings           -M-
>Reporting         -M-
Sensor Parameter  -M-
Machine Data      -M-
```

Display 4

As an addition to the preinstalled machines, user-defined machine types can be set as needed at the unused menu entries (a designation for the machine and its cylinder section have to be entered).

The Sensor Parameters sub-menu, used to calibrate the pressure and the temperature sensors, should be accessed by authorized staff only and is, therefore, protected by another access code disclosed only to such personnel as is allowed to manage these settings.

#### 4.1.1 Setting the Default Configuration of the Machine

In the sub-menus of the Configuration Menu, at "Settings," the parameters related to the welding unit itself and its operation can be set. At "Recording," the traceability data that have to or need not be recorded and written into the reports can be enabled or disabled. The desired sub-menu is selected using the  $\uparrow$  and  $\downarrow$  arrow keys. Then to access that sub-menu, press the MENU key.

In both parts of the configuration menu, use the  $\uparrow$  and  $\downarrow$  arrow keys to select the desired set-up option. Use the  $\Rightarrow$  arrow key to toggle between "on" and "off" for that set-up option.

If a "M" is shown next to a set-up option, this indicates that a sub-menu is accessible here by pressing the MENU key.



Important

On both menu levels (Configuration Menu and its respective sub-menus), press the START/SET key to save the settings to memory or press the STOP/RESET key to return to the previous menu level without saving possible changes.

```
>HST 160           1.95
HST 200            3.16
HST 250            5.10
HST 315            5.89
```

Display 5

#### 4.1.2 Understanding the "Settings" Sub-menu

"Check Code Expiry on" means that the welder identification code has to be current and not expired (default period of validity 2 years from code issuance), or the welding operation cannot be started, "off," that the validity of the code is not checked at all.

"Memory Control on" means that when the system memory is full of reports, the unit will be blocked until the reports are printed or downloaded, "off," that it works but that the oldest report will be overwritten.

"Automode on" means that in butt-welding operations the Automode feature for the easy management of the welding process (see Sect. 4.3.4) can be used, "off," that the feature is not available.

```
***   SETTINGS   ***
Check Code Exp. Off
Memory Control  On
>Automode      On
```

Display 6

“Manual Input on” means that the manual input of welding parameters or computed parameters is possible, “off,” that the manual input is not allowed.

“Check Ambient Temperature on” means that the outside temperature is measured before welding, “off,” that it not; if the temperature is below 0°C (32°F), welding should be performed only after taking appropriate steps (heating, tent, for instance).

“Welder Code Options – M – ” means that by pressing the MENU key, the user can access a sub-menu that allows determining when the welder code, if it is enabled at “Recording,” has to be entered: always, i. e. before every single welding operation, only before the first welding operation after switching the unit on or only after the first welding operation of a new day/date.

“Language – M – ” means that by pressing the MENU key, the user can access a sub-menu for selecting the display and report language (see Sect. 4.1.3).

“Date/Time – M – ” means that by pressing the MENU key, the user can access a sub-menu for setting the clock (see Sect. 4.1.4).

“Buzzer Volume – M – ” means that by pressing the MENU key, the user can access a sub-menu for setting the volume of the status buzzer (see Sect. 4.1.5).

“Temperature Unit – M – ” means that by pressing the MENU key, the user can access a sub-menu for selecting centigrade or Fahrenheit as the unit for the temperature.

“Pressure Unit – M – ” means that by pressing the MENU key, the user can access a sub-menu for selecting bars or pounds per square inch (psi) as the unit for the pressure.

“Length Unit – M – ” means that by pressing the MENU key, the user can access a sub-menu for selecting millimeters or inches as the unit for the length.

“Inventory Number – M – ” means that by pressing the MENU key, the user can access a sub-menu for entering the number under which the unit is inventorized with the operating company.

“Number of Tags – M – ” means that by pressing the MENU key, the user can access a sub-menu for entering the number of tags that are printed automatically after welding with the optional label tag printer if such a printer is connected.

“Standard – M – ” means that by pressing the MENU key, the user can access a sub-menu for selecting the standard (guideline, normative scheme) applicable to the welding operation.

### 4.1.3 Selecting the Display Language

When the “Select Language” sub-menu was selected, the screen changes and the display reproduced in Display 7 appears.

Use the arrow keys  $\uparrow$  and  $\downarrow$  to select one of the options, “Deutsch,” “English,” and “Français” and confirm by pressing the START/SET key.

```
***** LANGUAGE *****  
>Deutsch  
English  
Francais
```

Display 7

### 4.1.4 Setting the Clock

When the “Set Clock” sub-menu was selected, the screen changes and the display reproduced in Display 8 appears.

The time of day and the date can be set using the keypad. The portions “Hour,” “Minute,” “Day,” “Month,” and “Year” are set separately. Press the START/SET key to confirm your settings.

```
Date/Time  
21.06.13      14:28
```

Display 8

### 4.1.5 Setting the Buzzer Volume

When the “Set Volume” sub-menu was selected, the screen changes and the display reproduced in Display 9 appears. The buzzer can also

```
Buzzer Volume  
< -----20----- >
```

Display 9

be heard. Turn the buzzer volume up or down to the desired value using the ←, → arrow keys (from 0 to 100) and confirm your setting by pressing the START/SET key.

#### 4.1.6 Understanding the "Recording" Sub-menu

"Welder Code on" means that the welder identification code has to be entered as set with "Welder Code Options," "off," that this is impossible.

"Commission Number on" means that the commission number (job number) will have to be entered or confirmed before every new welding, "off" that the user is not prompted to enter it.

"Joint Number on" means that the unit assigns an automatically incremented joint number to every welding operation belonging to a commission already known, and displays this number on the screen next to the report number, "off" that no joint numbers will be assigned at all.

"Additional Data on" means that the additional data will have to be entered or confirmed before every new welding, "off" that the user is not prompted to enter them.

"Fitting Code on" means that the second, so-called traceability code of the fitting that is going to be worked has to be entered before every welding, "off," that this is not possible.

"Pipe Codes on" means that the codes of both pipes/components (ISO-compliant welding and traceability codes) have to be entered before every welding, "off," that this is not possible.

"Pipe Length on" means that the length of both pipes/components has to be entered before every welding, "off," that this is not possible.

"Weather Conditions on" means that the weather has to be selected in a list before every welding, "off," that this is not possible.

"Installing Company on" means that the company that performs the installation work has to be entered before every welding, "off," that this is not possible.

"Print Tags – M – " means that by pressing the MENU key, the user can access a sub-menu for starting to print (a) label(s) with reference to a given welding operation, with the optional label tag printer.

"Angle – M – " means that by pressing the MENU key, the user can access a sub-menu for entering the angle, in degrees, between the two components that are going to be welded.



Info

All data that are available in the chip of a transponder card can be entered by placing the card in front of the card reader. If they are encoded in a bar code, they can be read using the handheld scanner.

```

** CONFIGURATION **
>Welder Code      On
Commission No.    On
Joint No.         Off
    
```

Display 10

## 4.2 Entering Preformatted and User-defined Traceability Data

When the system is used in the WeldControl mode, all traceability data enabled in the configuration menu at "Recording" (see Sect. 4.1.6) have to be entered before the welding process. The welding unit prompts the user to enter them before the welding process proper. Depending on what data is entered, either its repeated input is mandatory (e. g., the welder ID code; see Sect. 4.1.2) or previously entered data can be changed and confirmed or confirmed without changes (e. g. the commission number; see Sect. 4.2.2).

```

Enter Welder Code
+++++
+++++
    
```

Display 11

### 4.2.1 Entering the Welder ID Code

When the welding is started by pressing the START/SET key while Display 3 is showing, first the input of the welder identification code is requested, if it is enabled in the Configuration Menu (see Display 11).

The code has to be an ISO-compliant code. It can be entered either using the cursor keys and confirming the input by pressing the START/SET key, or by reading a RFID transponder card or scanning it from a bar code with the optional handheld scanner.

When the code was properly scanned or entered, this is confirmed by an audible signal.

#### 4.2.2 Entering or Changing the Commission Number

From Display 3 or after the welder identification code was entered, the machine requests the input of the job number, or commission number, of a maximum 32 characters, if it was enabled in the Configuration Menu. If a commission number exists already in memory, this one is proposed. You can either confirm it by pressing START/SET or change it using the cursor keys or reading it with the scanner or from a RFID card and then confirm the new number by pressing the START/SET key.



Display 12

It is possible to select a previously saved commission number instead of the one shown on the screen by pressing the ⇐ and ⇒ cursor keys simultaneously. This causes the screen to show in which you can scroll through the commission numbers in memory using the ⇐ and ⇒ keys, to select a number and then confirm it by the START/SET key. This number will be used for the next welding. To quit the scroll mode without selecting a commission, press the STOP/RESET key.

#### 4.2.3 Entering or Changing the Joint Number

From Display 3 or after the commission number was entered, the machine requests the input of the welding number, or joint number, if it was enabled in the Configuration Menu.

The joint number, or welding number, is based on the job/commission number. This means that it increments by 1 for every welding operation performed in the scope of the current commission (identified previously by entering the appropriate job number). In the example in Display 3, the next welding operation will be saved to welding report number 72 while the joint itself is joint number 2 of the current job/commission.



Info

The first joint of a commission for which no joint has been saved to memory so far, always receives no. 1. If the memory already holds joints for a commission, the machine finds the highest number of the joints existing for that commission and uses this number plus 1. The user is shown the number thus found on the screen and can apply or change it. If the user changes the joint number, it is his responsibility to make sure that no number is assigned twice in one commission. If a joint number appears twice in a commission, this will not affect the welding process and the logging of its data in any way. However, in that commission two joints will not be distinguished by a unique number.

If user inputs leave some joint numbers unused (for instance, for a given commission no. 1, 2, 3, 5, 6, 9), the gaps do not get filled, and the automatically found number proposed for the next welding operation will still be the highest existing number plus 1 (that is, 10 in this example).

The joint number can also be entered after simultaneously pressing the cursor keys ⇐ and ⇒ when Display 3 is showing on the screen.

## 4.2.4 Entering oder Changing Further Data on Component Traceability

In the same way as welder identification code, commission and welding number, other data relating to the components can be entered if they were enabled in the Configuration Menu. They are requested in the following order (not all of them in both welding processes than can be used): length of the 1<sup>st</sup> pipe, code of the 1<sup>st</sup> pipe, length of the 2<sup>nd</sup> pipe, code of the 2<sup>nd</sup> pipe, code of the fitting, weather conditions, additional data (as defined by the user).



If pipe codes for the two pipes are entered and if those pipe codes state different sizes and/or Standard Dimension Ratios (SDR) for the pipes, then a code error is triggered since these welding parameters must be identical for both pipes.

```
Weather
>sunny
clear
rain
```

Display 13

All data can be entered by using the cursor keys and confirming by pressing the START/SET key or can be scanned from a bar code or an RFID card, if available, with the scanner or transponder reader. One exception is the weather (see Display 13). This option is presented as a list in which the applicable conditions can be selected by pressing  $\uparrow$  or  $\downarrow$  and confirmed by pressing the START/SET key.

## 4.3 Butt Welding in the WeldControl Mode

The welding process can be performed fully manually (Manual Mode) or with the support of the hydraulic, control, and data logging/report generation unit (WeldControl Mode), which displays all steps needed during welding on the screen to the welder's attention or has him confirm them, and which makes a report of the welding operation. No welding report is generated when the welding is fully manual.

Below, this booklet first presents the welding process in the WeldControl Mode. How welding is performed in the Manual Mode is explained from Section 4.4.



If the machine is set to Manual Mode (fully manual welding process without data logging/report generation), the operator can switch it to WeldControl Mode by pressing the  $\leftarrow$  and  $\rightarrow$  arrow keys simultaneously.

To start welding, clamp the pipes into the machine chassis. Use the appropriate reducer inserts if the component size is smaller than the basic machine chassis. When the fourth clamp of the machine is removed, tees and elbows can be processed. Then, to launch the welding process, press the START/SET key.

After all traceability data enabled in the configuration menu were entered, the parameters of the pipes to be welded have to be entered. If pipe parameters of an earlier welding are available and no code error was detected, all welding parameters of the previous welding are proposed and can be confirmed in one go (see Display 16).

From this display, it is possible to change the pipe parameters by pressing the STOP/RESET key. Then the first thing is to select the pipe material in a list; use the  $\uparrow$  and  $\downarrow$  cursor keys and confirm by pressing the START/SET key (see Display 14). Then the cursor keys allow entering the diameter and the wall thickness, both confirmed by the START/SET key (see Display 15). Instead of the wall thickness, you may want to enter the Standard Dimension Ratio (SDR); then display this input line instead of the wall thickness line by pressing the  $\leftarrow$  and  $\rightarrow$  simultaneously and enter the SDR value. The machine then displays

```
SELECT PIPE MATERIAL
>PE80
PE100
PP
```

Display 14

```
ENTER PIPE DIMENSION

Pipe Diameter:0250mm
Wallthickness:22.7mm
```

Display 15

```
Pipe Material: PE80
Pipe Diameter:0250mm
Wallthickness:22.7mm
RESET SDR11.0 SET
```

Display 16

the whole set of parameters as an overview. In case there are errors, it is possible either to enter all data once more by pressing the STOP/RESET key, or to return to the previous step by pressing  $\uparrow$  and correct the data one at a time.

If pipe codes were entered previously in the traceability data for the joint, the machine automatically presents the welding parameters contained in the pipe codes for confirmation.

#### 4.3.1 Facing the Pipe Butts

To ensure that the pipe butts are level, insert the pipe facing tool between the machine carriages and turn it on. Using the carriage mover lever on the hydraulic unit, have the movable carriage close in toward the center in order to bring the pipes into contact with the facing tool. Use the pressure regulator to adjust the pressure manually while the facing tool is trimming the pipes.



The farther the carriage mover lever is pushed to the left, the faster the carriage closes in and the faster pressure increases. The farther it is pushed to the right, the faster the carriage of the machine moves apart, and the faster pressure decreases.

Pipe facing should continue until shaving forms a continuous blade that rolls twice or three times around the pipe ends, so the butts are level. Facing is stopped by moving the carriage apart with the carriage mover lever.

If you discover after the facing process that the butts are still not level, start over, insert the facing tool and repeat the process. When facing is properly done, pipe alignment has to be checked.

The facing process is shown on the display screen (see Display 17). The START/SET key has to be pressed by the welder to confirm that facing is properly finished.

#### 4.3.2 Checking Pipe Alignment and Determining Drag Pressure

When the pipes are properly faced, close in the movable carriage completely to check whether a potential vertical and horizontal pipe misalignment is within the tolerance allowed by the applicable welding standard. The maximum acceptable gap between them is displayed (see Display 18). If pipe alignment is in order, the welding proper can start. If the misalignment is outside tolerance, the pipes must be readjusted in the clamps and, if needed, facing has to be repeated.


When pipe alignment is appropriate, move the carriage apart using the carriage mover lever; make sure the movable carriage is as far apart as possible before continuing. Turn the maximum pressure regulator counter-clockwise as far as it will go to have zero pressure in the hydraulic circuit. Then set the carriage mover lever to its close-in position while simultaneously turning the maximum pressure regulator gradually clockwise. Watch the display closely to observe at which pressure level the carriage is "dragged" to start moving.

The START/SET key has to be pressed when the carriage starts moving, in order to save the drag pressure applicable to this welding to memory.




Important


The exact drag pressure depends on various conditions (pipe size and material, position of the machine, etc.) and has to be determined for every welding individually.



Display 17



Display 18



Display 19



### 4.3.3 Possibility to Change Welding Parameters

Subsequent to setting the drag pressure, Display 20 shows on the screen, provided that manual data input is enabled in the Reporting sub-menu of the Configuration Menu.

```
Buildup pr.:030.5bar
Heatsoakpr.:010.5bar
Heatsoaking:0120 s
Change-over:0005 s
```

Display 20

In both screens enabling manual input of welding parameters (Displays 20 and 21), the ← and → cursor keys allow moving on from digit to digit and from value to value. The selected digit of a parameter value is changed using the ↑ and ↓. The START/SET key serves to confirm the inputs. By pressing the START/SET key, you also make the control unit go on to the next screen.



The parameters set manually are kept in memory when the machine is turned off. Only the pressure values are computed individually for every welding process. If the pipe parameters change, **all** parameters have to be set once again. The machine recognizes the change of pipe parameters and brings the operator directly to the menu for changing them.

```
Cool. time :900 s
Press. ramp:010 s
Plate temp.:223 °C
```

Display 21

### 4.3.4 Setting the Joining Pressure and Starting the Bead Build-up Stage

After butt facing and pipe alignment check, the welding process proper starts by setting the joining pressure (i.e., the maximum pressure that will be reached during the process, in the bead build-up stage and at the end of the joining stage). This is done by pressing the carriage close-in pushbutton and setting the maximum pressure regulator to the level to be kept during bead build-up and joining/cooling. The actual pressure shows (see Display 22) and the control software moves on to the next step as soon as the pressure is within tolerance.

```
Set Joining Pressure
230°C NOM. 16.5bar
229°C ACT. 3.5bar
```

Display 22

The display also shows the nominal joining pressure applicable to this welding. After setting the joining pressure, move apart the carriage of the machine.



The so-called automode is a tool for monitoring the duration of the bead build-up stage and moving on automatically from the bead build-up to the heating stage by decreasing the applied pressure. However, this requires that the automode was enabled in the Configuration Menu. Then, with enabled automode, Display 23 is shown. Then, to use that bead build-up time saved at the last welding operation, press START/SET. Pressing STOP/RESET will cancel the automode for bead build-up. If the bead build-up is automode-managed, the build-up time is displayed as a countdown, and from 10 sec prior to decreasing the pressure, the audible signal can be heard.

```
**** AUTOMODE ****
Use last bead
build-up time?
RESET SET
```

Display 23

At the start of the bead build-up stage, place the heating element between the pipe butts. The display tells you so. If the heating element is not sufficiently hot at this point, an information message on the screen asks you to wait a little longer.

```
Put in heat. plate
222°C NOM. 16.5bar
221°C ACT. 0.5bar
```

Display 24

Then close in the movable carriage by pressing the carriage close-in pushbutton and wait for the weld bead to reach the required height or width, depending on the used welding standard. Observing the bead is also highly recommended in the automode, even though the bead height is not indicated on the screen during an automode-managed bead build-up stage.

```
Bead Height :2.0mm
Bead Build Time:68 s
230°C NOM. 16.5bar
229°C ACT. 12.5bar
```

Display 25

### 4.3.5 Heating Stage

After the bead build-up stage (1<sup>st</sup> LED in the welding diagram on the control unit) was completed, pressure must be decreased (2<sup>nd</sup> LED in

the diagram). The decreased pressure will then be applied for the entire duration of the heat-soaking stage (3<sup>rd</sup> LED in the diagram), in which the pipe butts continue to soak heat from the plate.

When the bead build-up stage is not automode-managed, the pressure is decreased either with the manual pressure release valve or with the START/SET key, and the decrease has to be observed on the display. When the START/SET key is used, the hydraulic and control unit keeps the heating pressure below the required maximum throughout the heating stage by re-opening the release valve as needed if the pressure rises. If the welder uses the pressure release valve, this automatic control is **not** available. In this case, it is under the operator's responsibility to compensate for potential pressure fluctuations.

The machine also moves on to the heating stage if the welder decreases the pressure to a level below the heat-soaking maximum before the countdown of the bead build-up stage is completely over – which may happen if the bead is o.k. earlier than expected. However, such a pressure decrease has to be quick. In these cases, the bead build-up time shortened by the early decrease is saved to memory as the build-up time for this welding and will be used as a reference for possible automode-managed build-up stages at a later time.



Important

Full contact has to be continuously established between the heating plate and the bead, even with lower pressure. While heating, if contact between them is lost somewhere along the circumference, welding has to be aborted and repeated.

If the control unit detects an error (such as insufficient pressure not readjusted by the welder or excessive heating time), it also aborts welding and displays an error message.

#### 4.3.6 Change-over Stage



Info

An audible signal indicates the imminent change-over during the last 10 seconds of the heat-soaking stage.

At the end of the heating stage, push the mover lever on the hydraulic unit to its move-apart position in order to move the carriage apart. Then remove the heating plate from in-between the pipes.

In the change-over stage, too, all relevant parameters are shown on the screen.

The change-over has to be followed immediately by the joining stage. The change-over time given on the display must not be exceeded. If it is, the welding is aborted automatically and an error is displayed.

#### 4.3.7 Joining and Cooling Stage

Set the carriage mover lever to its close-in position again in order to move the pipe butts in on each other and build the joining pressure. Watch the value on the screen. Building the joining pressure must correspond to a linear increase, as predicted by the nominal values on the screen. The 5<sup>th</sup> LED of the diagram on the hydraulic unit flashes.

Once the joining pressure is reached and has stabilized, the pressure will be kept at this level until the end of the joining/cooling stage (6<sup>th</sup> LED in the diagram). In this stage, the new joint already starts cooling down.



Important

Right after the end of the linear pressure ramp, at the very beginning of the cooling, pressure may drop slightly for

HEAT SOAK PHASE		
Heat Soak Time	:	148s
230°C	MAX	5.0bar
229°C	ACT.	3.5bar

Display 26

Remove plate		
Change-over	:	8 s
230°C	MAX	5.0bar
229°C	ACT.	3.5bar

Display 27

Build Joining Press.		
230°C	NOM.	16.5bar
229°C	ACT.	14.5bar

Display 28

COOLING PHASE		
Cooling time	:	1234s
230°C	NOM.	16.5bar
229°C	ACT.	16.5bar

Display 29

COOLING PHASE		
Cooling time over	:	
229°C	ACT.	0.0bar

Display 30

technical reasons. The welder has to compensate for this drop immediately by pushing the carriage mover lever. In this case, the first line of Display 28 reads, "Keep the pressure."

Depending on the welding standard used or on information provided by the pipe or fitting manufacturer, a cool-on time may be required during which the new joint must not be exposed to external forces. This, however, is not monitored by the hydraulic, control, and data logging unit, for which the welding has to be considered finished when the 7<sup>th</sup> LED is lit.

#### 4.3.8 End of Welding

The welding is finished at the end of the successful joining and cooling stage. The machine releases the pressure on the pipes automatically.

#### 4.4 Fully Manual Butt-welding Process



When you want to weld fully manually, the machine has to be switched to Manual Mode. To do so, press the ⇐ and ⇒ arrow keys simultaneously while "Next Welding" is showing on the screen. In the manual mode, the display screen looks like what Display 31 shows.

In a fully manual welding process, pipe facing, pipe alignment check, determination of the pressure to "drag" the carriage along and of the joining pressure (i.e., the maximum pressure of the welding, reached during bead build-up and joining) have to be performed in the exact same way as in the SPG Mode (see the relevant sub-sections of Section 4.3). The only difference is that the display does not provide any hints as to what to do. It just works as a digital gauge indicating the actual pressure applied to the pipes (see Display 31). It also shows the nominal temperature the welder has to set and the actual temperature of the heating element, and it monitors and controls the temperature throughout the process. The parameters for proper welding have to be looked up in the welding value tables in the appendix.

*** MANUAL MODE ***	
220°C	NOM. ---.-bar
219°C	ACT. 016.0bar

Display 31



The farther the carriage mover lever is pushed to the left, the faster the carriage closes in and the faster pressure increases. The farther it is pushed to the right, the faster the carriage of the machine moves apart, and the faster pressure decreases.

The nominal temperature, at which the hydraulic and control unit should keep the heating element, can be changed using the ↑ and ↓ cursor keys. After such a change, the display shows the actual temperature changing slowly to the new nominal temperature.




Important

The welder must wait for the display to show the new nominal temperature before using the machine!

The welding proper has the four stages in the diagram below that are explained in the following sections. It is under the welder's responsibility to verify the correct welding pressures and times.

Before the welding process starts, the drag pressure has to be determined with care. Move the movable carriage apart, turn the pressure regulator counter-clockwise as far as it will go, then bring to mover lever to the close-in position and gradually turn the pressure regulator clockwise. Watch the display and note the pressure that "drags" the carriage sufficiently to set it in motion. This is the drag pressure  $P_t$  for this welding.



Important

The exact drag pressure depends on various conditions (pipe size and material, position/altitude of the machine, etc.) and has to be determined for every welding individually. The value  $P_t$  is needed to compute the bead build-up, the heating, and the joining pressures needed for joining (stages  $t_1$ ,  $t_2$ , and  $t_5$  in the welding diagram respectively).

#### 4.4.1 Bead Build-up Stage

Use the welding value tables in the Appendix to look up the joining pressure (maximum pressure to be applied during bead build-up and joining) appropriate for your situation. Then set the maximum pressure regulator to the appropriate pressure while observing the actual pressure displayed on the screen, and move apart the carriage of the machine. Insert the heating element (heating plate), move the carriage in on the plate and press the pipe butts to the plate at a pressure of  $P_1 + P_t$  for the bead build-up duration given in the welding value tables in the Appendix ( $t_1$  in the diagram below).

#### 4.4.2 Heating Stage

After the bead build-up stage ( $t_1$  in the diagram) was completed, the pressure must be decreased to below or equal to the level of  $P_2 + P_t$ . The decreased pressure will then be applied for the entire duration of the heating stage ( $t_2$  in the diagram), in which the pipe butts continue to soak heat from the plate. Use the welding value tables in the Appendix to determine the heat-soaking time ( $t_2$ ) and the heat-soaking pressure ( $P_2 + P_t$ ) applicable to your welding situation.



Info

In the Manual and in the WeldControl Modes, two ways to reduce the applied pressure are available. Either open the pressure release valve or press the START/SET key. Pressing the START/SET key reduces the pressure only as long as you hold the key down.



Important

Full contact has to be continuously established between the heating plate and the bead, even with lower pressure. While heating, if contact between them is lost somewhere along the circumference, welding has to be aborted and repeated.

#### 4.4.3 Change-over Stage

After the end of the heating, or heat-soaking, stage, set the carriage mover lever on the hydraulic unit to its move-apart position in order to move the carriage to the far end. Then remove the heating element from in-between the pipes.

The change-over has to be followed immediately by the joining stage. The change-over time given for your welding situation in the tables in the Appendix ( $t_3$ ) must not be exceeded. If it is, welding has to be aborted and repeated.

#### 4.4.4 Joining and Cooling Stage

Set the carriage mover lever to its close-in position again in order to move the pipe butts in on each other and to build the joining pressure ( $P_s + P_r$ ) according to a consistent increase. Watch the value on the display screen. Building the joining pressure must correspond to a linearly increasing ramp and its duration must neither be longer nor shorter than indicated for your welding situation in the welding value tables in the Appendix at  $t_4$ .

Once the joining pressure is reached and has stabilized at  $P_s + P_r$ , the pressure will be kept at this level until the end of the joining phase ( $t_5$  in the diagram). In this stage, the new joint also starts cooling down.

Pipe and fitting manufacturers may include data on how long the new joint should not be exposed to external strain. Also, the applicable welding standard may require a minimum cool-on time ( $t_6$  in the diagram). In most cases, however,  $t_6$  is not relevant to the welder.


#### 4.4.5 End of Welding

The welding is finished at the end of a successful joining and cooling stage. The welder has to shut the pressure off from the pipes using either the manual pressure release valve or the START/SET key.

#### 4.5 Aborted Welding Process

If an error condition is detected, the machine aborts the welding process and displays the error. However, this is only possible when welding according to the WeldControl mode of the butt-welding process. In the Manual Mode of butt welding, error detection is not available.

The error that made the welding abort is displayed on the screen (see Display 32). Additionally, in the welding diagram the LED that belongs to the welding stage with the malfunction starts flashing.



Display 32

The errors listed in the following table can be displayed on the screen.

Type of Error	Description
<b>a. Data Input</b>	
Input Error	Error while entering data with the cursor keys.
Code Error	Error while reading data from a bar code or an RFID card.
<b>b. System and Conditions</b>	
System Error	The welding system has to be disconnected immediately from both the power supply and the fitting. The auto-test has detected an error in the system. The welder must no longer be operated and has to be sent to an approved shop for check and repair.
Clock Error	The internal clock of the machine is defective; re-set the clock in the Configuration Menu.
Unit to Service	The recommended next service date for the welder is overdue. The service due message has to be acknowledged by pressing the START/SET key. Send the welding system to the manufacturer or an approved service point for service and check-up.
Power Supply Failure at Last Welding	The last welding is incomplete. The welding unit was disconnected from the power supply voltage while it was in progress. To go on using the unit, this error has to be acknowledged by pressing the STOP/RESET key.
Ambient Temperature high	Outside temperature outside the range from $-20^{\circ}\text{C}$ to $+60^{\circ}\text{C}$ .
Ambient Temperature low	Outside temperature outside the range from $-20^{\circ}\text{C}$ to $+60^{\circ}\text{C}$ .

Type of Error	Description
Overheated	The temperature of the control and hydraulic unit is too hot. Let the welding system cool down for about 1 hour.
Pressure Sensor Defective	The sensor indicated on the display (hydraulic pressure, heating element temperature, ambient temperature) is defective; where possible, check the connections/plug; have the machine inspected by an authorized service shop if needed.
Heating Sensor Defective	
Temperature Sensor Defective	
Printer not Ready (only label tag printer)	The optional printer is not ready (possible reasons also: no communication or faulty cable).
Download Cancelled	During data transfer or printing, an error condition occurred which could not be cleared.
Memory Full	The system memory is full of welding reports. Print or download the reports in memory or switch memory control off. Without memory control, a new report overwrites the oldest existing one.
<b>c. Welding Process</b>	
Temperature low	Heating element temperature will be increased automatically.
Temperature high	Heating element temperature will be reduced automatically.
Error Changeover	It took too long to retract the heating plate and bring the pipes to joining; welding will have to be repeated.
Error Drag Pressure	Impossible to determine the drag pressure; maybe pipes will have to be clamped once again; or the pressure is below 1 bar, which is not feasible for technical reasons.
Error Build-up Pressure	Build-up pressure too high or too low and was not re-adjusted in time.
Error Heat Soak Pressure	Heat-soaking pressure too high and was not re-adjusted in time.
Error Joining Pressure	Joining pressure too high or too low and was not re-adjusted in time.
Cooling Stopped	Operator has stopped the cooling time by pressing the STOP/REST key.
Error Plate Temperature	Heating element temperature is out of tolerance; impossible to re-adjust the temperature; maybe the ambient temperature was too low.

#### 4.6 Using ViewWeld to View Welding Reports and Print Tags

The ViewWeld feature offers viewing an abstracted version of the welding report recorded during the last welding process and printing it as a label tag to be affixed to the joint on the optionally available tag printer. The ViewWeld abstract shows the report number, the date and time of the welding and the welding parameters along with an evaluation of the quality of the joint/welding operation (see Display 33).

To call the ViewWeld abstract of a welding report, press the  $\uparrow$  key in the start screen (see Display 3). To print a tag of this operation, press the START/SET key in the ViewWeld screen.

After the ViewWeld abstract was accessed, it is possible to browse through all abstracts in memory by pressing the  $\leftarrow$  and  $\rightarrow$  keys.

```
0015 24.02.13 09:33
HST 315
No Error
```

Display 33

## 5 Downloading the Reports

Interface

### USB A Interface Port

for connecting USB mass storage media (such as a memory stick)

The interface port complies with the USB version 2.0 specification (i.e., maximum data rate of 480 megabits per second).



Important

Before transferring data, it is highly recommended to switch the welding unit off and on again. If this fails to happen, there is a risk of data transfer failure, or reports in the welding unit may be corrupted.



Important

When transferring welding reports to a USB stick, always be sure to wait until the display shows the "Download finished" message before you disconnect the USB stick from the product. If you disconnect it too early, the unit may ask you whether you want to delete the reports in memory, although they were not properly transferred. In this case, if you delete the contents of the report memory, the welding reports would be irrevocably lost and would not be available elsewhere either.

### 5.1 Selecting the File Format

Connecting the storage media causes the the screen to appear in which the format of the output file with the welding reports can be selected: a PDF file with an abstracted or extended version of the report or the format of the welding data management application DataWork. Using the  $\uparrow$  and  $\downarrow$  arrow keys, select the file type you need and confirm your selection by pressing the START/SET key.

The Service Report option is not important for normal operation. In the scope of computer-assisted unit service, this report lists the events related to the maintenance of the welding unit.

### 5.2 Downloading All Reports

After the file type was selected, the next screen offers a "Print All Reports" option. Selecting it will download all welding reports currently in system memory, or all of the previously selected welding process, in the previously selected file format.

```
* Select File Type *
DataWork File
>PDF Abstract
PDF Ext'd Report
```

Display 34

### 5.3 Downloading by Commission Number, Date or Report Range

After the file type was selected, the next screen offers a "By Commission Number," a "By Date Range," and a "By Report Range" options. Depending on the selection, the  $\uparrow$  and  $\downarrow$  arrow keys can be used to select from the commissions currently in system memory the desired one, of which the reports should be downloaded, or the alphanumeric keypad can be used (see first info in Sect. 4.1) to enter a start date and an end date, or the first and the last report, that define a range of dates or a range of reports of which the reports should be downloaded. When you press the START/SET key, you cause the selected reports to be transferred to the storage media.

### 5.4 Understanding the Report Download Process

The download starts automatically after a selection was made among the options. Wait for all the selected reports to transfer and the "Download completed" message to appear on the screen.

If a problem occurs while the download is in progress, a "Not ready" message shows. After the problem condition is cleared, the download resumes automatically.



Info

If the welding unit recognizes a problem that cannot be cleared while the data transfer is in progress, it does not resume the process and displays a "Download cancelled" error message. To acknowledge this error, press the START/SET key.

### 5.5 Deleting Data from Memory

The report data in memory can be deleted only after all welding reports were transferred, which is indicated by the "Download completed" message. When the storage media is unplugged, a "Delete Memory" message appears. If the START/SET key is pressed at this point, a further confirmation message "Delete Memory, sure?" is shown, which has to be confirmed by pressing the START/SET key once again. Then, the report data in memory are deleted.

### 5.6 Keeping Data in Memory

When the cable or storage media is unplugged, a "Delete Memory" message is displayed. Press the STOP/RESET key to keep the current report data in memory. They can then be printed off once again.



Important

Make a habit of handling the internal storage as described at the beginning of Sect. 5, to maintain data integrity and avoid any inadvertent deletion of the reports in memory.

## 6 Service and Repair

As the product is used in applications sensitive to safety considerations, it may be serviced and repaired only on our premises or by partners who were specifically trained and authorized by us. Thus, constantly high standards of operation quality and safety are maintained.



Important

Non-compliance with this provision will dispense the manufacturer from any warranty and liability claims for the product and any consequential damage.

## 7 Service and Repair Contact

HÜRNER Schweisstechnik  
Nieder-Ohmener Str. 26  
35325 Mücke, Germany

Tel.: +49 (0)6401 9127 0  
Fax: +49 (0)6401 9127 39

Web: [www.huerner.de](http://www.huerner.de)

E-mail: [info@huerner.de](mailto:info@huerner.de)



Info

We reserve the right to change technical specifications of the product without prior notice.

## 8 Accessories/Parts for the Product

Facing Tool Blade for HÜRNER WeldControl 2.0 160



Info

Only genuine spare parts are acceptable. The use of non-genuine parts voids any and all liability and warranty on the part of the manufacturer.



For consultation and ordering spare parts, refer to the seller or manufacturer of the product.

Schweißtabellen  
Welding Value Tables  
Paramètres de soudage

## HÜRNER WeldControl 2.0 160



Technische Änderungen an der Maschine bleiben vorbehalten.

We reserve the right to change technical specs of the machine without prior notice.

Nous nous réservons le droit d'apporter des modifications techniques sans préavis.

PE 80 / PE 100 DVS 2207-1 (09/2005)		HÜRNER WeldControl 2.0 160 Zylinder/Cylinder/Vérin 1,95 cm <sup>2</sup>				Angleichen Bead Build-up		Anwärmen Heating		Um- stellen Change- over	Fügerampe (t <sub>3</sub> ), Fügen u. Abkühlen Pressure Ramp (t <sub>4</sub> ), Joining and Cooling		
Durchmesser Diameter mm	Wandstärke Wall Thickn. mm	Ø / Wand Ø / Wall SDR	Versatz Align Offset mm	Temperatur Temperature °C (PE 80)	Temperatur Temperature °C (PE 100)	P <sub>1</sub> bar	Wulst Bead mm	P <sub>2</sub> max. bar	t <sub>2</sub> sec	t <sub>3</sub> max. sec	t <sub>4</sub> sec	P <sub>5</sub> bar	t <sub>6</sub> min
40	1,6	26	0,2	220	220	1,0	0,5	0,0	45	5	5	1,0	6
40	1,9	21	0,2	220	220	1,5	0,5	0,0	45	5	5	1,5	6
40	2,3	17,6	0,3	220	220	2,0	0,5	0,0	45	5	5	2,0	6
40	2,4	17	0,3	220	220	2,0	0,5	0,0	45	5	5	2,0	6
40	2,9	13,6	0,3	220	220	2,5	0,5	0,0	45	5	5	2,5	6
40	3,6	11	0,4	219	220	3,0	0,5	0,0	45	5	5	3,0	6
40	4,4	9	0,5	219	220	3,5	0,5	0,5	45	5	5	3,5	6
40	5,4	7,4	0,6	218	220	4,5	1,0	0,5	54	5	5	4,5	8
50	1,9	26	0,2	220	220	2,0	0,5	0,0	45	5	5	2,0	6
50	2,4	21	0,3	220	220	2,5	0,5	0,0	45	5	5	2,5	6
50	2,8	17,6	0,3	220	220	3,0	0,5	0,0	45	5	5	3,0	6
50	2,9	17	0,3	220	220	3,0	0,5	0,0	45	5	5	3,0	6
50	3,7	13,6	0,4	219	220	4,0	0,5	0,5	45	5	5	4,0	6
50	4,5	11	0,5	218	220	4,5	0,5	0,5	45	5	5	4,5	6
50	5,6	9	0,6	217	220	6,0	1,0	0,5	55	5	5	6,0	8
50	6,8	7,4	0,7	216	220	7,0	1,0	0,5	68	5	5	7,0	10
63	2,4	26	0,3	220	220	3,5	0,5	0,0	45	5	5	3,5	6
63	3,0	21	0,3	220	220	4,0	0,5	0,5	45	5	5	4,0	6
63	3,6	17,6	0,4	220	220	5,0	0,5	0,5	45	5	5	5,0	6
63	3,7	17	0,4	219	220	5,0	0,5	0,5	45	5	5	5,0	6
63	4,6	13,6	0,5	218	220	6,0	1,0	0,5	46	5	5	6,0	7
63	5,7	11	0,6	217	220	7,5	1,0	1,0	57	5	6	7,5	8
63	7,0	9	0,7	216	220	9,0	1,0	1,0	70	6	6	9,0	10
63	8,5	7,4	0,9	215	220	11,0	1,5	1,0	85	7	7	11,0	12
75	2,9	26	0,3	220	220	5,0	0,5	0,5	45	5	5	5,0	6
75	3,6	21	0,4	220	220	6,0	0,5	0,5	45	5	5	6,0	6
75	4,3	17,6	0,5	219	220	7,0	0,5	0,5	45	5	5	7,0	6
75	4,4	17	0,5	219	220	7,5	0,5	1,0	45	5	5	7,5	6
75	5,5	13,6	0,6	217	220	9,0	1,0	1,0	55	5	5	9,0	8
75	6,8	11	0,7	216	220	11,0	1,0	1,0	68	6	6	11,0	10
75	8,3	9	0,9	215	220	13,0	1,5	1,5	83	7	7	13,0	12
75	10,1	7,4	1,0	213	220	15,5	1,5	2,0	101	7	7	15,5	14



Angleichdruck    *Bead Build-up Pressure*    = P<sub>1</sub> + P<sub>t</sub> (Bewegungsdruck    *Drag Pressure*)  
 Anwärmdruck    *Heat Soaking Pressure*        = P<sub>2</sub> + P<sub>t</sub> (Bewegungsdruck    *Drag Pressure*)  
 Fügedruck        *Joining Pressure*                    = P<sub>5</sub> + P<sub>t</sub> (Bewegungsdruck    *Drag Pressure*)

<b>PE 80 / PE 100</b> DVS 2207-1 (09/2005)		<b>HÜRNER WeldControl 2.0 160</b> Zylinder/Cylinder/Vérin 1,95 cm <sup>2</sup>				<b>Angleichen</b> <i>Bead Build-up</i>		<b>Anwärmen</b> <i>Heating</i>		<b>Um- stellen</b> <i>Change- over</i>	<b>Fügerampe (t<sub>2</sub>), Fügen u. Abkühlen Pressure Ramp (t<sub>2</sub>), Joining and Cooling</b>		
Durchmesser <i>Diameter</i>	Wandstärke <i>Wall Thicken.</i>	Ø / Wand Ø / Wall	Versatz <i>Align Offset</i>	Temperatur <i>Temperature</i>	Temperatur <i>Temperature</i>	P <sub>1</sub>	Wulst <i>Bead</i>	P <sub>2</sub> max.	t <sub>2</sub>	t <sub>3</sub> max.	t <sub>4</sub>	P <sub>5</sub>	t <sub>6</sub>
mm	mm	SDR	mm	°C (PE 80)	°C (PE 100)	bar	mm	bar	sec	sec	sec	bar	min
90	3,5	26	0,4	220	220	7,0	0,5	0,5	45	5	5	7,0	6
90	4,3	21	0,5	219	220	8,5	0,5	1,0	45	5	5	8,5	6
90	5,1	17,6	0,5	218	220	10,0	1,0	1,0	51	5	5	10,0	7
90	5,3	17	0,6	218	220	10,5	1,0	1,0	53	5	5	10,5	7
90	6,6	13,6	0,7	216	220	13,0	1,0	1,5	66	6	6	13,0	9
90	8,2	11	0,9	215	220	16,0	1,5	2,0	82	7	7	16,0	11
90	10,0	9	1,0	213	220	19,0	1,5	2,5	100	7	7	19,0	13
90	12,2	7,4	1,3	211	220	22,5	2,0	3,0	122	8	8	22,5	15
110	4,2	26	0,5	219	220	10,5	0,5	1,0	45	5	5	10,5	6
110	5,2	21	0,6	218	220	13,0	1,0	1,5	52	5	5	13,0	7
110	6,2	17,6	0,7	217	220	15,5	1,0	2,0	62	6	6	15,5	9
110	6,5	17	0,7	217	220	16,0	1,0	2,0	65	6	6	16,0	9
110	8,1	13,6	0,9	215	220	19,5	1,5	2,5	81	6	6	19,5	11
110	10,0	11	1,0	213	220	24,0	1,5	3,0	100	7	7	24,0	14
110	12,2	9	1,3	211	220	28,5	2,0	3,5	122	8	8	28,5	16
110	14,9	7,4	1,5	209	220	34,0	2,0	4,5	149	8	9	34,0	19
125	4,8	26	0,5	218	220	13,5	1,0	1,5	48	5	5	13,5	6
125	6,0	21	0,6	217	220	17,0	1,0	2,0	60	6	6	17,0	8
125	7,1	17,6	0,7	216	220	20,0	1,5	2,5	71	6	6	20,0	10
125	7,4	17	0,8	216	220	21,0	1,5	2,5	74	6	6	21,0	10
125	9,2	13,6	1,0	214	220	25,5	1,5	3,0	92	7	7	25,5	13
125	11,4	11	1,2	212	220	31,0	1,5	4,0	114	8	8	31,0	15
125	13,9	9	1,4	210	220	37,0	2,0	4,5	139	9	9	37,0	18
125	16,9	7,4	1,7	208	220	44,0	2,0	5,5	169	9	10	44,0	22
140	5,4	26	0,6	218	220	17,5	1,0	2,0	54	5	5	17,5	7
140	6,7	21	0,7	216	220	21,5	1,0	2,5	67	6	6	21,5	9
140	8,0	17,6	0,8	215	220	25,5	1,5	3,0	80	6	6	25,5	10
140	8,2	17	0,9	215	220	26,0	1,5	3,0	82	7	7	26,0	12
140	10,3	13,6	1,1	213	220	32,0	1,5	4,0	103	7	7	32,0	14
140	12,7	11	1,3	211	220	39,0	2,0	5,0	127	8	8	39,0	17
140	15,6	9	1,6	209	220	46,5	2,0	6,0	156	9	10	46,5	20
140	18,9	7,4	1,9	207	220	55,0	2,0	7,0	190	10	11	55,0	24
160	6,2	26	0,7	217	220	23,0	1,0	3,0	62	6	6	23,0	9
160	7,6	21	0,8	215	220	27,5	1,5	3,5	76	6	6	27,5	10
160	9,1	17,6	1,0	214	220	33,0	1,5	4,0	91	7	7	33,0	12
160	9,4	17	1,0	214	220	34,0	1,5	4,5	95	7	7	34,0	13
160	11,8	13,6	1,2	212	220	42,0	1,5	5,0	119	8	8	42,0	16
160	14,5	11	1,5	210	220	50,5	2,0	6,5	146	9	9	50,5	19
160	17,8	9	1,8	207	220	61,0	2,0	8,0	179	10	11	61,0	23
160	21,6	7,4	2,2	205	220	72,0	2,5	9,5	219	10	12	72,0	27



Angleichdruck *Bead Build-up Pressure* = P<sub>1</sub> + P<sub>t</sub> (Bewegungsdruck *Drag Pressure*)  
 Anwärmdruck *Heat Soaking Pressure* = P<sub>2</sub> + P<sub>t</sub> (Bewegungsdruck *Drag Pressure*)  
 Fügedruck *Joining Pressure* = P<sub>5</sub> + P<sub>t</sub> (Bewegungsdruck *Drag Pressure*)

<b>PP</b> DVS 2207-11 (02/2017)		HÜRNER WeldControl 2.0 160 Zylinder/Cylinder/Vérin 1,95 cm <sup>2</sup>			Angleichen <i>Bead Build-up</i>		Anwärmen <i>Heating</i>		Um- stellen Change- over	Fügerampe (t <sub>4</sub> ), Fügen u. Abkühlen Pressure Ramp (t <sub>4</sub> ), Joining and Cooling		
Durchmesser Diameter mm	Wandstärke Wall Thickn. mm	Ø / Wand Ø / Wall SDR	Versatz Alignment Offset mm	Temperatur Temperature °C	P <sub>1</sub> bar	Wulst Bead mm	P <sub>2</sub> m <sub>ax.</sub> bar	t <sub>2</sub> sec	t <sub>3</sub> m <sub>ax.</sub> sec	t <sub>4</sub> sec	P <sub>5</sub> bar	t <sub>6</sub> min
40	1,0	41	0,1	210	0,5	0,5	0,0	53	5	6	0,5	6,5
40	1,2	33	0,1	210	0,5	0,5	0,0	53	5	6	0,5	6,5
40	1,5	26	0,2	210	0,5	0,5	0,0	53	5	6	0,5	6,5
40	2,3	17,6	0,3	210	1,0	0,5	0,0	53	5	6	1,0	6,5
40	3,6	11	0,4	210	2,0	0,5	0,0	53	5	6	2,0	6,5
40	4,4	9	0,5	210	2,5	0,5	0,0	53	5	6	2,5	6,5
40	5,4	7,4	0,6	210	3,0	0,5	0,0	63	5	6	3,0	7,5
40	6,7	6	0,7	210	3,5	0,5	0,0	78	5	6	3,5	9,0
50	1,2	41	0,1	210	0,5	0,5	0,0	53	5	6	0,5	6,5
50	1,5	33	0,2	210	1,0	0,5	0,0	53	5	6	1,0	6,5
50	1,9	26	0,2	210	1,0	0,5	0,0	53	5	6	1,0	6,5
50	2,8	17,6	0,3	210	2,0	0,5	0,0	53	5	6	2,0	6,5
50	4,5	11	0,5	210	3,0	0,5	0,0	53	5	6	3,0	6,5
50	5,6	9	0,6	210	4,0	0,5	0,0	65	5	6	4,0	8,0
50	6,8	7,4	0,7	210	4,5	0,5	0,0	79	5	6	4,5	9,5
50	8,3	6	0,9	210	5,5	1,0	0,5	95	6	8	5,5	11,0
63	1,5	41	0,2	210	1,0	0,5	0,0	53	5	6	1,0	6
63	1,9	33	0,2	210	1,5	0,5	0,0	53	5	6	1,5	6
63	2,4	26	0,3	210	2,0	0,5	0,0	53	5	6	2,0	6
63	3,6	17,6	0,4	210	3,0	0,5	0,0	53	5	6	3,0	6
63	5,7	11	0,6	210	5,0	0,5	0,5	66	5	6	5,0	9
63	7,0	9	0,7	210	6,0	0,5	0,5	81	6	7	6,0	12
63	8,5	7,4	0,9	210	7,0	1,0	0,5	97	6	8	7,0	15
63	10,5	6	1,1	210	8,5	1,0	0,5	119	7	9	8,5	18
75	1,8	41	0,2	210	2,0	0,5	0,0	53	5	6	2,0	6,5
75	2,3	33	0,3	210	2,5	0,5	0,0	53	5	6	2,5	6,5
75	2,9	26	0,3	210	3,0	0,5	0,0	53	5	6	3,0	6,5
75	4,3	17,6	0,5	210	4,5	0,5	0,0	53	5	6	4,5	6,5
75	6,8	11	0,7	210	7,0	0,5	0,5	79	6	7	7,0	9,5
75	8,3	9	0,9	210	8,5	1,0	0,5	95	6	8	8,5	11,0
75	10,1	7,4	1,0	210	10,5	1,0	1,0	114	7	10	10,5	13,0
75	12,5	6	1,3	210	12,5	1,0	1,0	140	7	11	12,5	16,0
90	2,2	41	0,3	210	3,0	0,5	0,0	53	5	6	3,0	6,5
90	2,7	33	0,3	210	3,5	0,5	0,0	53	5	6	3,5	6,5
90	3,5	26	0,4	210	4,5	0,5	0,0	53	5	6	4,5	6,5
90	5,1	17,6	0,5	210	6,5	0,5	0,5	60	5	6	6,5	7,0
90	8,2	11	0,9	210	10,5	1,0	1,0	94	6	8	10,5	11,0
90	10,0	9	1,0	210	12,5	1,0	1,0	113	7	9	12,5	13,0
90	12,2	7,4	1,3	210	15,0	1,0	1,5	137	7	11	15,0	15,5
90	15,0	6	1,5	210	18,0	1,0	1,5	165	8	14	18,0	19,0



Angleichdruck *Bead Build-up Pressure* = P<sub>1</sub> + P<sub>t</sub> (Bewegungsdruck *Drag Pressure*)  
 Anwärmdruck *Heat Soaking Pressure* = P<sub>2</sub> + P<sub>t</sub> (Bewegungsdruck *Drag Pressure*)  
 Fügedruck *Joining Pressure* = P<sub>5</sub> + P<sub>t</sub> (Bewegungsdruck *Drag Pressure*)

<b>PP</b> DVS 2207-11 (02/2017)		HÜRNER WeldControl 2.0 160 Zylinder/Cylinder/Vérin 1,95 cm <sup>2</sup>			Angleichen <i>Bead Build-up</i>		Anwärmen <i>Heating</i>		Um- stellen Change- over	Fügerampe (t <sub>4</sub> ), Fügen u. Abkühlen Pressure Ramp (t <sub>4</sub> ), Joining and Cooling		
Durchmesser Diameter mm	Wandstärke Wall Thickn. mm	Ø / Wand Ø / Wall SDR	Versatz Alignment Offset mm	Temperatur Temperature °C	P <sub>1</sub> bar	Wulst Bead mm	P <sub>2</sub> m <sub>ax.</sub> bar	t <sub>2</sub> sec	t <sub>3</sub> m <sub>ax.</sub> sec	t <sub>4</sub> sec	P <sub>5</sub> bar	t <sub>6</sub> min
110	2,7	41	0,3	210	4,5	0,0	0,0	53	5	6	4,5	6,5
110	3,3	33	0,4	210	5,5	0,0	0,5	53	5	6	5,5	6,5
110	4,2	26	0,5	210	7,0	0,5	0,5	53	5	6	7,0	6,5
110	6,2	17,6	0,7	210	10,0	0,5	1,0	72	6	7	10,0	8,5
110	10,0	11	1,0	210	16,0	1,0	1,5	113	7	9	16,0	13,0
110	12,2	9	1,3	210	17,0	1,5	1,5	137	7	11	17,0	15,5
110	14,9	7,4	1,5	210	22,5	1,5	2,0	164	8	13	22,5	19,0
110	18,3	6	1,9	210	27,0	2,0	2,5	199	9	16	27,0	23,0
125	3,0	41	0,3	210	5,5	0,5	0,5	53	5	6	5,5	6,5
125	3,8	33	0,4	210	7,0	0,5	0,5	53	5	6	7,0	6,5
125	4,8	26	0,5	210	9,0	0,5	0,5	56	5	6	9,0	7,0
125	7,1	17,6	0,8	210	13,0	1,0	1,0	82	6	7	13,0	9,5
125	11,4	11	1,2	210	20,5	1,0	2,0	129	7	10	20,5	15,0
125	13,9	9	1,4	210	24,5	1,0	2,0	154	8	13	24,5	18,0
125	16,9	7,4	1,7	210	29,0	1,0	2,5	185	8	15	29,0	21,5
125	20,1	6	2,0	210	33,5	1,5	3,0	216	10	18	33,5	25,5
140	3,4	41	0,4	210	7,0	0,5	0,5	53	5	6	7,0	6,5
140	4,2	33	0,5	210	9,0	0,5	0,5	53	5	6	9,0	6,5
140	5,4	26	0,6	210	11,5	0,5	1,0	63	5	6	11,5	7,5
140	8,0	17,6	0,8	210	17,0	1,0	1,5	92	6	8	17,0	10,5
140	12,7	11	1,3	210	26,0	1,0	2,5	142	7	12	26,0	16,5
140	15,6	9	1,6	210	31,0	1,0	3,0	172	8	14	31,0	20,0
140	18,9	7,4	1,9	210	36,5	1,0	3,5	205	9	17	36,5	24,0
140	23,3	6	2,4	210	43,5	1,5	4,0	246	10	20	43,5	29,0
160	3,9	41	0,4	210	9,5	0,5	0,5	53	5	6	9,5	6,5
160	4,8	33	0,5	210	12,0	0,5	1,0	56	5	6	12,0	7,0
160	6,2	26	0,7	210	15,0	0,5	1,5	72	6	7	15,0	8,5
160	9,1	17,6	0,9	210	22,0	1,0	2,0	104	6	9	22,0	12,0
160	14,5	11	1,5	210	33,5	1,0	3,0	160	8	13	33,5	18,5
160	17,8	9	1,8	210	40,5	1,0	4,0	194	9	16	40,5	22,5
160	21,6	7,4	2,2	210	48,0	1,5	4,5	230	10	19	48,0	27,0
160	26,7	6	2,7	210	57,0	2,0	5,5	277	11	26	57,0	33,0



Angleichdruck *Bead Build-up Pressure* = P<sub>1</sub> + P<sub>t</sub> (Bewegungsdruck *Drag Pressure*)  
 Anwärmdruck *Heat Soaking Pressure* = P<sub>2</sub> + P<sub>t</sub> (Bewegungsdruck *Drag Pressure*)  
 Fügedruck *Joining Pressure* = P<sub>5</sub> + P<sub>t</sub> (Bewegungsdruck *Drag Pressure*)